

# Installation Manual

## Green RTU Configuration



## Green RTU Configuration

### Communication Setup

Ag/MIS/ImEn-2767-05/20 Rev 1.6

P/N: 116815



# Green RTU Configuration

## User Manual

Revision: N. 1.6 of 06.2024

Product Software: N/A

This manual for use and maintenance is an integral part of the apparatus together with the attached technical documentation.

This document is destined for the user of the apparatus: it may not be reproduced in whole or in part, committed to computer memory as a file or delivered to third parties without the prior authorization of the assembler of the system.

Munters reserves the right to effect modifications to the apparatus in accordance with technical and legal developments.

# Index

<i>Chapter</i>		<i>page</i>
<b>1</b>	<b>INTRODUCTION .....</b>	<b>4</b>
1.1	Disclaimer.....	4
1.2	Introduction .....	4
1.3	Notes .....	4
<b>2</b>	<b>CONFIGURATION .....</b>	<b>5</b>
2.1	Introduction .....	6
2.2	Controller – Transmitter Setup .....	11
2.2.1	Controller Setup.....	11
2.2.2	Wiring.....	12
2.3	Setting up the G5 Transmitter .....	14
2.3.1	Mounting the Transmitter .....	14
2.3.2	Defining the Dipswitches.....	15
2.4	Setting Up the Green RTU.....	16
2.4.1	Mounting the Green RTU .....	16
2.4.2	Programing.....	16
2.5	Green Field Controller Set Up .....	17
2.5.1	Communication Protocol.....	17
2.5.2	Defining Remote Relays.....	18
2.6	Trouble Shooting and Testing .....	18
<b>3</b>	<b>WARRANTY .....</b>	<b>19</b>

# 1 Introduction

## 1.1 Disclaimer

Munters reserves the right to make alterations to specifications, quantities, dimensions etc. for production or other reasons, subsequent to publication. The information contained herein has been prepared by qualified experts within Munters. While we believe the information is accurate and complete, we make no warranty or representation for any particular purposes. The information is offered in good faith and with the understanding that any use of the units or accessories in breach of the directions and warnings in this document is at the sole discretion and risk of the user.

## 1.2 Introduction

Congratulations on your excellent choice of purchasing a Green RTU Units!

In order to realize the full benefit from this product it is important that it is installed, commissioned and operated correctly. Before installation or using the units, this manual should be studied carefully. It is also recommended that it is kept safely for future reference. The manual is intended as a reference for installation, commissioning and day-to-day operation of the Munters Controllers.

## 1.3 Notes

Date of release: May 2020

Munters cannot guarantee to inform users about the changes or to distribute new manuals to them.

*NOTE All rights reserved. No part of this manual may be reproduced in any manner whatsoever without the expressed written permission of Munters. The contents of this manual are subject to change without notice.*

## 2 Configuration

This manual contains the information needed for a basic setup. For more detailed information go to Munters' on-line manual library.

This document lists the basic steps to be done when installing Munters Green RTU Units. For complete information on the products and their installation, refer to the following documents:

- Serial Transmitter Module Installation Manual (P/N 116809)
- Radio Repeater Module Installation Manual (P/N 116810)
- RTU RX Module Installation Manual (P/N 116812)
- G5 RX Module Programming Manual (P/N 116811)

For more information on any of these products:

[Go to Munters.com](#)

Or

Contact your Business Unit



## 2.1 Introduction

The following document describes how to set up the Serial Transmitter Module. In doing so, you can define exactly how the Green Field Controller manages all valves.



Figure 1: Transmitter



Figure 2: Green RTU



Figure 3: Repeater



Figure 4: Hand Held Programmer




Figure 5: Kit and RTU Modules Components (see the following table)

Drawing No.	Description	Munters PN
1	HOST KIT MUR 915 MHZ	960-20-00023
	HOST KIT MUR 433 MHZ	960-20-00024
2	GREENHOUSE RF-RTU 915 MODULE 2 LINE WITHOUT SOLENOID	960-20-00012
	GREENHOUSE RF-RTU 433 MODULE 2 LINE WITHOUT SOLENOID	960-20-00013
	GREENHOUSE RF-RTU 915 MODULE 4 LINE WITHOUT SOLENOID	960-20-00014
	GREENHOUSE RF-RTU 433 MODULE 4 LINE WITHOUT SOLENOID	960-20-00015






Figure 6: Spare Parts (see the following table)

Drawing No.	Description	Munters PN
1	GATOR - 433MHz UNIVERSAL TXRX MODULE (SERTX)	960-20-00002
	GATOR - 915MHz UNIVERSAL TXRX MODULE (SERTX)	960-20-00001
2	GATOR - 433MHz UNIVERSAL TXRX MODULE (REPEAT)	960-20-00004
	GATOR - 915MHz UNIVERSAL TXRX MODULE (REPEAT)	960-20-00003
3	ANT - GALV MOUNT BRAC 3 PNT X 100 DEEP	960-99-00068
	ANT - GALV MOUNT BRAC 3 PNT X 250 DEEP	960-99-00071
	ANT - GALV MOUNT BRAC 3 PNT X 470 DEEP	960-99-00072
4	POWER SUP - 220VAC~12VDC, 0.5AMP ADAPTOR	960-99-00062
5	ANT - 433MHz DIPOLE ANTENNAE ALUMINIUM H/D	960-99-00059
	ANT - OMNI DIRECTIONAL OUTDOOR 915MHZ	960-99-00070
6	GREENHOUSE CABLE - CAT 15M WITH 2 X RJ45 CONNS	960-99-00083
7	CABLE - ANT 01M X RG58 M N & M SMA CON	960-99-00067
8	U BOLT - M08 X 50MM GALV M/S	960-99-00069
9	HAND HELD PROGRAMMER FOR CONTROL MODULE	960-99-00065
10	CABLE RJ45 CAT5E 26AWG WITH METAL SHIELDED (SP-140314)	960-99-00095
11	GREENHOUSE RF-RTU 915 MODULE 2 LINE WITHOUT SOLENOID	960-20-00012
	GREENHOUSE RF-RTU 433 MODULE 2 LINE WITHOUT SOLENOID	960-20-00013
	GREENHOUSE RF-RTU 915 MODULE 4 LINE WITHOUT SOLENOID	960-20-00014
	GREENHOUSE RF-RTU 433 MODULE 4 LINE WITHOUT SOLENOID	960-20-00015
12	NETWORK - PASSIVE MODIF POE 5-45VDC	960-99-00061

## 2.2 Controller – Transmitter Setup

- Controller Setup
- Wiring

### 2.2.1 CONTROLLER SETUP

Observe the following points when setting up the Green Field Controller and G5 Transmitter.

- The Green Field Controller must have a License Card.




Figure 7: License Card and Placement

- The Controller can have 24VAC local relays (for pumps, fertigation, filters, etc.). Figure 8 shows 16 local 24VAC outputs; remote outputs start from relay 17.




Figure 8: 24VAC Relays

## 2.2.2 WIRING

- Connect the Controller to the Transmitter as shown in the following diagram.




Figure 9: Green Field – G5 Transmitter Block Diagram

- Figure 13 displays
- The only connection that requires wiring is the Green Field Communication Card. Wire this card to the RJ-45 Male cable as shown in Figure 10.




Figure 10: Communication Card Wiring




Figure 11: Communication Card Placement

- Use the PoE device to connect the RJ45 cables as detailed below:



Figure 12: Communication Card Wiring

- LAN: RJ45 cable from the Green Field Controller
- PoE: RJ45 cable to the Transmitter
- 12 VDC: Power cable

**CAUTION** *Disconnecting the power supply means that wireless connectivity ceases! Ensure that the 12VDC power cable is secured and cannot be disconnected while the system is operating!*

- Connect the antenna cable (Figure 13).




Figure 13: Transmitter Cables

## 2.3 Setting up the G5 Transmitter

- Mounting the Transmitter
- Defining the Dipswitches

### 2.3.1 MOUNTING THE TRANSMITTER

- Installing and mounting the unit: Refer to the Serial Transmitter Module Installation Guide.



## 2.3.2 DEFINING THE DIPSWITCHES




Figure 14: Dipswitches

- 1. The Transmitter dipswitch is used to define the system ID, number of outputs, and radio channel.
  - Switch 1 defines the System ID. All units in a single system must have the same ID number to ensure transmission.
    - Example: Switch 1.8 means that the ID is 1.

SYSTEM ID	Dipswitch Bank	1							
1	Switch Number	1	2	3	4	5	6	7	8
	Associated Binary Value	0	0	0	0	0	0	0	1
	Select the Switch Setting	Off	Off	Off	Off	Off	Off	Off	On

- Set 2 defines the number of maximum outputs, baud rate, and the radio channel:
  - Dipswitches 2.1, 2.2, and 2.3 define the number of outputs. 256 outputs is the maximum number of outputs.

OUTPUTS	Dipswitch Bank	2		
256	Switch Number	1	2	3
	Associated Binary Value	4	2	1
	Select the Switch Setting	On	On	On

Dipswitch Number	2.1	2.2	2.3	Number of outputs
Position	Off	Off	Off	32
	Off	Off	On	64
	Off	On	Off	96
	Off	On	On	128

Dipswitch Number	2.1	2.2	2.3	Number of outputs
	On	Off	Off	160
	On	Off	On	192
	On	On	Off	224
	On	On	On	256

- Dipswitch 2.4 remains in the 0 position. This defines the baud rate.

BAUD RATE	Dipswitch Bank	2				
9600	Switch Number		4			
	Associated Binary Value		0			
	Select the Switch Setting		Off			

- Dipswitch 2.5, 2.6, 2.7, and 2.8 define the radio channel. Refer to the Serial Transmitter Module Installation Guide for more information on defining the radio channel.

CHANNEL NUMBER	Dipswitch Bank	2				
5	Switch Number		5	6	7	8
	Associated Binary Value		0	0	0	1
	Select the Switch Setting		Off	On	Off	On

## 2.4 Setting Up the Green RTU

- Mounting the Green RTU
- Programming

### 2.4.1 MOUNTING THE GREEN RTU

- Refer to the RTU RX Module Installation Manual for detailed instructions on mounting and powering the unit and on connecting it to output devices.

### 2.4.2 PROGRAMMING

- Refer to the G5 RX Module Programming Manual for detailed instructions on using the programmer.

Using the Hand Held Programmer, define the Green RTU communication parameters.



Figure 15: Programmer Screen



1. Connect the Programmer to the Green RTU.
2. Press the Red Button on the DB9 cover for two seconds.
3. Define:
  - NW: Communication wireless protocol (read only)
  - CO1: This is the channel
  - I00:XXX is the system ID, in which X must match the transmitter System ID.
  - M is the number of receiver outputs. In the above figure, the receiver controls four outputs.
  - V:00X: This number defines which outputs are activated. Each receiver controls four consecutive outputs. X is the number of the first valve in the series. For example, if X is 9, the GTU RX controls valves 9, 10, 11, and 12.


## 2.5 Green Field Controller Set Up

- Communication Protocol
- Defining Remote Relays

### 2.5.1 COMMUNICATION PROTOCOL

The following procedure details how to define the Green Field Controller communication protocol.

1. On the Green Field screen, go to Setup > System Setup.
2. Scroll down to Communication.
3. Define the Remote Unit Type as SN/SF NET.




**NOTE** All remote units connected to the Green Field Controller must use be connected via radio.

4. Define the relevant parameters (baud rate).
5. Apply power to both units. After ten seconds, "Host Unit Error" should appear on the Green Field Controller screen.

## 2.5.2 DEFINING REMOTE RELAYS

1. On the Green Field screen, go to Installation > Device Layout.
2. Relays 17 – 20 are remote unit relays. Define them as valves.



The screenshot shows a window titled 'DEVICE LAYOUT' with a table of relay definitions. The table has three columns: 'Relay', 'Function', and 'No.'. The rows are as follows:

Relay	Function	No.
LOCAL	Main valve	12
LOCAL	Pump	13
LOCAL	Filter	14
LOCAL	Filter	15
LOCAL	Agitator	16
U.	Valve	17
U.	Valve	18
U.	Valve	19
U.	Valve	20
U.	None	21

3. Repeat for each Green RTU.

## 2.6 Trouble Shooting and Testing

Problem: Valve definition does not match dipswitch definition.

Explanation: Dipswitches define the maximum number of valves. If the Hand Held Programmer defines valves about this range, an error is recorded.

For example

Dipswitches 2.1, 2.2, and 2.3 are in the Off position; this enables up to 32 valves. If the Programmer defines V:032, valve 32 is turned on, but valves 33, 34, and 35 are errors.

# 3 Warranty

## Warranty and technical assistance

Munters products are designed and built to provide reliable and satisfactory performance but cannot be guaranteed free of faults; although they are reliable products they can develop unforeseeable defects and the user must take this into account and arrange adequate emergency or alarm systems if failure to operate could cause damage to the articles for which the Munters plant was required: if this is not done, the user is fully responsible for the damage which they could suffer.

Munters extends this limited warranty to the first purchaser and guarantees its products to be free from defects originating in manufacture or materials for one year from the date of delivery, provided that suitable transport, storage, installation and maintenance terms are complied with. The warranty does not apply if the products have been repaired without express authorisation from Munters, or repaired in such a way that, in Munters' judgement, their performance and reliability have been impaired, or incorrectly installed, or subjected to improper use. The user accepts total responsibility for incorrect use of the products.

The warranty on products from outside suppliers fitted to the Green RTU units, (for example cables, power supplies, etc.) is limited to the conditions stated by the supplier: all claims must be made in writing within eight days of the discovery of the defect and within 12 months of the delivery of the defective product. Munters has thirty days from the date of receipt in which to take action, and has the right to examine the product at the customer's premises or at its own plant (carriage cost to be borne by the customer).

Munters at its sole discretion has the option of replacing or repairing, free of charge, products which it considers defective, and will arrange for their despatch back to the customer carriage paid. In the case of faulty parts of small commercial value which are widely available (such as bolts, etc.) for urgent despatch, where the cost of carriage would exceed the value of the parts, Munters may authorise the customer exclusively to purchase the replacement parts locally; Munters will reimburse the value of the product at its cost price.

Munters will not be liable for costs incurred in demounting the defective part, or the time required to travel to site and the associated travel costs. No agent, employee or dealer is authorised to give any further guarantees or to accept any other liability on Munters' behalf in connection with other Munters products, except in writing with the signature of one of the Company's Managers.

***WARNING: In the interests of improving the quality of its products and services, Munters reserves the right at any time and without prior notice to alter the specifications in this manual.***

The liability of the manufacturer Munters ceases in the event of:

- dismantling the safety devices;
- use of unauthorised materials;

- inadequate maintenance;
- use of non-original spare parts and accessories.

Barring specific contractual terms, the following are directly at the user's expense:

- preparing installation sites;
- providing an electricity supply (including the protective equipotential bonding (PE) conductor, in accordance with CEI EN 60204-1, paragraph 8.2), for correctly connecting the equipment to the mains electricity supply;
- providing ancillary services appropriate to the requirements of the plant on the basis of the information supplied with regard to installation;
- tools and consumables required for fitting and installation;
- lubricants necessary for commissioning and maintenance.

It is mandatory to purchase and use only original spare parts or those recommended by the manufacturer.

Dismantling and assembly must be performed by qualified technicians and according to the manufacturer's instructions.

The use of non-original spare parts or incorrect assembly exonerates the manufacturer from all liability.

Requests for technical assistance and spare parts can be made directly to the nearest [Munters office](#).

