

EC

Manual for use and maintenance



+ EU Declaration of conformity

EC

Air extraction fan

Models: EC52 - EC50

Ag/MIT/UmEN-2742-07/24 Rev 1.2

 **Munters**

EC

Manual for use and maintenance

Original instructions

Revision 1.2

This manual for use and maintenance is an integral part of the apparatus together with the attached technical documentation and has been produced with reference to Directive 2006/42/EC, paragraph A, Annex II, and to ErP Directive 2009/125/CE Commission Regulation 327/2011.

This document is destined for the user of the apparatus: it may not be reproduced in whole or in part, committed to computer memory as a file or delivered to third parties without the prior authorisation of the assembler of the system.

Munters Italy S.p.A. reserves the right to effect modifications to the apparatus in accordance with technical and legal developments and to make alterations to specifications, quantities, etc., for production or other reasons, subsequent to publication.

Warranty

For Warranty information please refer to "General terms and condition of sale" available on https://www.munters.com/globalassets/terms-and-policies/condizioni_generali_vendita.pdf

Conditions and Limitations:

- Products and Systems involved in a warranty claim under the "General terms and condition of sale" shall have been properly installed, maintained and operated under competent supervision, according to the instructions provided by Munters;
- Malfunction or failure resulting from misuse, abuse, negligence, alteration, accident or lack of proper installation or maintenance shall not be considered a defect under the Warranty.



CONTENTS

1. EU DECLARATION	5
1.1 Disclaimer	6
1.2 Introduction	6
1.3 Notes	6
1.4 Data for Fan Eco Design Directive	7
1.5 Attached technical documentation	8
1.6 Disposal	8
2. SAFETY ASPECTS	9
2.1 Personnel requirements	9
2.2 General safety instructions	10
2.3 Safety devices	11
2.4 Residual risks	13
3. BEFORE USING	16
3.1 Delivery check	16
3.2 Packaging and transport of assembled fans	16
3.3 Structure	18
4. OPERATING CONDITIONS	19
4.1 Intended conditions of use	19
4.2 Non-permitted conditions of use	20
5. INSTALLATION	22
5.1 Choice of site and checking installation requirements	22
5.2 Assembly of the EC52 cone	23
5.3 Assembly of the EC50 cone	26
5.4 Placement of fans	28
5.5 Connection to the electrical system	30
5.6 Tests and checks before startup	36
6. INVERTER	38
6.1 Working range	38
6.2 Leds	38
6.3 Alarm	40
6.4 Mobile device APP	40
7. COMMISSIONING	49
7.1 Control devices	49
7.2 Instructions for starting up	49
8. TECHNICAL DATA	51
8.1 Dimensions	51
8.2 Technical specifications	52

9. MAINTENANCE55
9.1 Introduction55
9.2 Routine Maintenance Program55
9.3 Cleaning.....56
9.4 Belt tensioning check up.....56

10. SPARE PART LIST58
EC52 exploded view58
Spare parts EC5261
EC50 exploded view65
Spare parts EC5068

1. EU DECLARATION

EU DECLARATION OF CONFORMITY

(complies with Subparagraph A Annex II Directive 2006/42/EC)

Munters Italy S.p.A.

with registered offices in Strada Piani, 2 – 18027 Chiusavecchia (IM) – Italy
(Company Registration nr. 00081050080)

declares on its own responsibility that the apparatus:

Designation	Fan designed for moving air to control temperature and humidity in greenhouses or rearing sheds.
Model	EC50 - EC52

CONFORMS WITH THE ESSENTIAL SAFETY REQUIREMENTS
STATED
BY APPARATUS DIRECTIVE 2006/42/EC AND PERFORMANCE
REQUIREMENTS

COMPLY WITH THE ERP DIRECTIVE 2009/125/CE.

with particular reference to the following provisions:

UNI EN 953:2009, UNI EN ISO 12100:2010, UNI EN ISO 12499:2009,
UNI EN ISO 13857:2008, CEI EN 60204-1:2006 (CEI 44-5), UNI EN ISO
5801:2009

Chiusavecchia, 15th July 2024

Daniela Giglioli



Legal Representative

1.1 Disclaimer

Munters reserves the right to make alternations to specifications, quantities, dimensions etc. for production or other reasons, subsequent to publication. The information contained herein has been prepared by qualified experts within Munters. While we believe the information is accurate and complete, we make no warranty or representation for any particular purposes. The information is offered in good faith and with the understanding that any use of the units or accessories in breach of the directions and warnings in this document is at the sole discretion and risk of the user.

1.2 Introduction

Congratulations on your excellent choice of purchasing a Munters fan!

In order to realize the full benefit from this product it is important that it is installed, commissioned and operated correctly. Before installation or using the fan, this manual should be studied carefully. It is also recommended that it is kept safely for future reference. The manual is intended as a reference for installation, commissioning and day-to-day operation of the Munters fans.

1.3 Notes

Date of release: 2024.

Munters cannot guarantee to inform users about the changes or to distribute new manuals to them.

All rights reserved. No part of this manual may be reproduced in any manner whatsoever without the expressed written permission of Munters. The contents of this manual are subject to change without notice.

1.4 Data for Fan Eco Design Directive

Product information requirements → (according to ANNEX I -3.2 of regulation)	1	2	3	4	optional	5	6a	6b	6c	7	8
Fan description ⁽¹⁾	Overall efficiency $\eta\%$	Measurement category	Efficiency category	Efficiency grade	Target efficiency grade 2015	VSD must be installed with the fan	Motor power input at optimum energy efficiency [W]	Flow rate at optimum energy efficiency [m ³ /h]	Pressure at optimum energy efficiency [Pa]	RPM at optimum energy efficiency	Specific ratio
EC52 2.0hp 3ph 50Hz OS	37,2	A	static	41,9	40	no	1.827	30.164	81,1	458	1
EC52 1.5hp 3ph 50Hz OS	35	A	static	40,2	40	no	1.499	30.377	62,1	438	1
EC52 1.0hp 3ph 50Hz OS	35,7	A	static	41,7	40	no	1.142	28.982	50,7	383	1
EC50 1.5hp 3ph 50Hz OS	35,3	A	static	40,5	40	no	1.528	32.651	59,5	501	1
EC50 1.0hp 3ph 50Hz OS	34	A	static	40,3	40	no	1.001	24.883	49,4	418	1
EC50 1.6hp 3ph 50/60Hz E-Line	40.7	A	static	46.1	40	yes	1.444	27.229	72.3	504	1

* Fans tested are configured according to COMMISSION REGULATION (EU) No 327/2011 of 30th March 2011 - ANNEX II - 1.5. Efficiency values, according to Commission Regulation (EU) 327/2011, refers to exhaust fans only.

1.5 Attached technical documentation

The listed documentation is to be considered an integral part of this manual:

- technical sheet/electric motor instruction booklet.

1.6 Disposal

Do not dispose of this product with general household waste. This product must be disposed according to the laws governing Waste Electrical and Electronic Equipment. If required, contact your local authorities for information regarding the available disposal facilities.

2. SAFETY ASPECTS



WARNING Failure to respect safety or behavioral rules can produce hazardous situations for users as well as damage to the machine and the place where it is installed. The fan must only be used if it is in perfect operating condition, by personnel who are perfectly aware of the safety measures and possible hazards, and in strict compliance with the instructions given in this manual.

2.1 Personnel requirements

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance

Equipment may only be used by personnel who know and apply the specific requirements given in the user and maintenance manual and the more general instructions contained in various regulations for accident prevention and applicable legislation regarding safety in the workplace, as well as other European Community directives incorporated by the member states into their national legislation.

Knowledge and understanding of the manual and of the attached documents constitute an indispensable tool for reducing hazards and promoting the safety and health of workers.

Personnel training

All operators engaged in the use of the fan must have received adequate information from the employer relating to:

- risks to health and safety at work connected with the use of the machine;
- first aid procedures, fire precautions and evacuation of workplaces;
- devices provided for the safety of operators, and residual risks generated by the machine.

In particular, the employer has the following duties:

- when assigning tasks to operators, to take into account their capabilities in the interests of safeguarding their health and safety;
- to provide adequate means of protection;
- to require compliance by individual operators with the company rules and provisions regarding safety and the use of the collective and individual protective measures at their disposal;

- to ensure that normal and special maintenance operations, or in any event operations necessary for machine safety, are regularly carried out.

All operators must take care of their own safety and health as well as that of other people in the workplace who may be affected by their actions or omissions, in accordance with their personal skills, and the instructions and means provided to them by the employer.



WARNING Unauthorized tampering/replacement of one or more parts of the machine, or the use of accessories, tools or materials other than those recommended by the manufacturer, are prohibited and release the manufacturer from all liability.



- WARNING** Operators must be trained to deal with the occurrence of possible faults, malfunctions or dangerous conditions to themselves or others, and in such an event must:
- stop the fan immediately by operating the emergency stop device (mushroom-shaped pushbutton/main switch mounted on the electrical panel);
 - not carry out operations which are beyond their duties and/or technical knowledge.

2.2 General safety instructions



- WARNING**
- Safety devices must not be removed or rendered ineffective;
 - the fan must not be started with guards removed;
 - any adjustment or maintenance operation must be performed with the electrical isolating device activated and locked in position with a padlock;
 - any operation is prohibited which may cause arcing or sparks or other situations which could start a fire;
 - in the event of alarm signals resulting in the intervention of safety devices, the operator must ask for immediate action by qualified technicians responsible for maintenance;
 - user must ensure that the environmental and electricity supply conditions in which the fan operates are always within the limits specified in this user manual;
 - do not for any reason modify parts of the fan in order to fit additional devices.

2.3 Safety devices

In the process of designing and building the fan, the manufacturer adopted the necessary technical solutions to ensure compliance with fundamental safety requirements: the object of the risk reduction process was to ensure that the operator can use the fan in safety. The machine is provided with protection devices of fixed type and is fitted with an actuator for the emergency stop function.

Fixed guards

The fixed guards are solidly fixed to the structure of the machine and cannot easily be eluded: the guards are fixed with systems which require the use of tools for dismantling.



WARNING Do not start the fan with fixed guards removed: the guards can only be removed with special tools, by specialized and trained personnel and with the system stationary (emergency system activated and electricity and hydraulic fluid isolated). At the end of maintenance operations, the guards which were removed must be replaced correctly.

Position of guard	Type of guard	Notes
Intake side of fan	Guard of fixed type made of metal mesh.	Dimensions and positioning in accordance with the instructions in the standard UNI EN 13857. Removable only by means of special tool.




fig.1

Outlet side of fan

Guard of fixed type
made of metal mesh.

Dimensions and positioning
in accordance with the
instructions in the standard
UNI EN 13857. Removable
only by means of special
tool.




fig.2

Emergency stop function



fig.3


The machine must be equipped at the installation stage with an electrical panel, on which must be installed an actuator for the emergency stop function, which when operated brings dangerous movements to a halt by isolation of the power supply: the button must be mushroom-shaped and coloured red, provided with mechanical restraint and released by turning.

2.4 Residual risks


Hazards generated by noise (<i>measured at 2m distance</i>)	
Fan model	Sound pressure level Lp [dB(A)]
EC52 - 2 hp	77.5
EC52 - 1.5 hp	77.1
EC52 - 1 hp	76.2
EC50 - 1.5 hp	77
EC50 - 1 hp	74.8
EC50 – 1.6 hp E-Line	75.1

A measurement has been made of the noise produced by the machine during normal operation in order to calculate the equivalent level in conditions of normal use. These values are shown in the above table.

Mechanical hazards		
Part of machine / stage of use	Description	Plates/provisions/PPE

Installation of machine	Hazard arising from failure to observe ergonomic principles, caused by excessive strain, i.e. generic mechanical hazard during the moving and installing stages of the machine.	 <p>fig.4</p>
-------------------------	---	--

Electrical hazards

System area	Description	Plates/provisions/PPE
Panels, covers and electrical apparatus.	The safety signs must be fixed in an extremely visible position on the door of the electrical panel and on covers containing electrical apparatus, to highlight the risks to which an operator could be exposed in the event of opening the electrical panel (danger resulting from the presence of live parts), the level of voltage present, the prohibition of tampering by unauthorized personnel and the prohibition on the use of liquids on electrical apparatus in the event of fire.	 <p>fig.5</p>



WARNING The user and the employer must comply with current national law in terms of protection against daily personal exposure of operators to noise, by providing the use of personal protective equipment (earmuffs, earplugs, etc.) if necessary, depending on the overall level of sound pressure in the installation area, and the daily personal exposure of the employees. In areas where the overall sound level reaches excessive values, personal protective equipment must be used.



WARNING The fan must only be used if it is in perfect operating condition, by personnel, aged more than 14 years who are perfectly aware of the safety measures and possible hazards, and in strict compliance with the instructions given in this manual.


3. BEFORE USING

3.1 Delivery check

Upon receipt, inspect the fan for external damage and if found, inform the forwarding agent without delay. Check the data on all the rating plates, especially voltage and frequency. Turn the propeller by hand while the fan is switched off to verify smooth rotation of the propeller.

3.2 Packaging and transport of assembled fans

The fan has a self-supporting structure in galvanised steel and it is usually delivered without packaging. Upon request fans can be delivered packed in cardboard boxes.






fig.7

restore them by mean of a screw-driver and re-check the opening of the shutter.

Follow the steps shown in the pictures.




fig.8

Fans should not be permanently stocked one upon the other, regardless if they are delivered with or without packaging. Handling of the fans should not be done manually as the fans have no handles or grips. Consequently, one of the following alternatives should be used:

- forklift: before loading, make sure the forks are opened as much as possible to avoid bending of the fan bottom panel;
- crane: fix two bolts in the M8 bushes situated on the sides of the fan housing and hook the lifting cable over the bolts.



WARNING Make sure a steel cable or rope of adequate size is being used when the fan is lifted by crane. Fan weights are shown in the technical specification table (see *section 7.2*).

3.3 Structure

The fans consist of the following components:


- fan housing in Munters Protect coated steel without welding spots;
- fan shutter in Munters Protect coated steel, which pivots on UV protected plastic bushes and pins;
- propeller with four blades in stainless or Munters Protect coated steel; blades are fixed to the propeller by high-strength pop rivets;
- motor: single-phase or three-phases; 50 or 60 Hz; B3 form; F class winding insulation, IP55 IEC protective class; asynchronous single-speed;
- centrifugal operated shutter opening device.
- Meshes for protection on back and front side.

4. OPERATING CONDITIONS

4.1 Intended conditions of use

Fans are machines designed for moving air to control temperature and humidity in greenhouses or rearing sheds by extraction, not under pressure. They can even be installed horizontally, without altering or modifying their characteristics.

Normal ambient temperature limits are -15°C to $+40^{\circ}\text{C}$. Maximum altitude is 1000m above sea level. Should a fan be required to operate at a higher altitude, the loss in mass flow (heat removing capacity) due to lower air density should be taken into consideration.



The fan has been designed and built to operate in safety for the user, if used according to the conditions intended by the manufacturer and stated in this user and maintenance manual.



NOTE For further information, please refer to the technical documentation attached to this manual.

4.2 Non-permitted conditions of use

Total or partial failure to observe the instructions given in this manual could cause damage to the fan and/or people.

The following uses are to be considered not permitted and improper:

- use in the event of faults and/or tampering with the installed safety devices;
- use by personnel not specifically trained;
- installation of the fan for extraction or circulation under pressure;
- use contrary to existing regulations;
- incorrect installation differing from instructions given in this manual;
- supply from an electrical network with characteristics different from that specified in the wiring diagram;
- total or partial failure to observe instructions;
- insufficient maintenance;
- use of non-original spare parts;
- use of lubricants with characteristics different from those specified in the technical documentation attached to the manual;
- use by minors;
- use under the influence of drugs, alcohol, etc.



WARNING Use of the fan other than as described in the user manual or outside the operational limits laid down by the manufacturer is considered IMPROPER USE. In the event of IMPROPER USE the manufacturer declines all liability in relation to any damage that may be caused to persons or property, and any kind of warranty will be considered invalidated.



WARNING If unusual oscillating movement is observed, immediately stop using the fan and contact the manufacturer, its service agent or suitably qualified persons.

Use of non-original spare parts

Original spare parts ensure the reliability and safety of the operation of the fan: in the event of maintenance/replacement, consult the spare parts list, the list of parts and components used and the relevant technical documentation attached to this manual.



WARNING In the event of replacement of safety devices, it is essential to maintain the safety and operational characteristics of the original device, preferring replacement with an identical component.

The replacement of parts of the safety suspension system device shall be performed by the manufacturer, its service agent or suitably qualified persons.

Insufficient maintenance

A correct normal maintenance is one that maintains the original integrity or restores the fan's efficiency, while at the same time limiting normal deterioration resulting from use.

Special maintenance work can also prolong the usable life of the machine and/or, secondarily, can improve its efficiency, reliability, productivity and ease of maintenance and inspection.

Unauthorized modifications or tampering

No operation is permitted which is aimed at making modifications to the fan and the safety devices fitted to it; similarly, it is not possible to alter its operational and performance characteristics.



WARNING Interference with the command and control circuits is prohibited: such operations could cause damage to the equipment and serious danger to the operator.



NOTE Modifications made to the fan which do not come into the categories of normal and special maintenance, or which alter its operational and performance characteristics, invalidate the machine's compliance with the requirements of the applicable directives, as attested by the manufacturer with the EC declaration of conformity: it is up to the person responsible for the modification to resubmit the machine to the assessment conformity procedures specified in the applicable directives.

Use in a potentially explosive atmosphere

The fan has been designed and built to operate in environments where the presence of a potentially explosive atmosphere is not expected, in other words it is not intended to handle materials which release explosive dust. Emission into the atmosphere of harmful particles or gases must be contained within the limits established by current regulations.



WARNING The fan has been designed and built in such a way that it **CANNOT** operate in a classified area, according to directive 1999/92/EC.



WARNING The metal sheets used for constructing the fan housing and shutter blades have a surface coating made of an alloy of Zinc, Aluminum and Magnesium, classified as Zm120 (equivalent to 9 µm of coating thickness on each side of the panels) which corresponds to a corrosion resistance in salty mist of 1800 hours.

Whenever it is intended to use the fans in ambients characterized by the presence of particularly aggressive agents (ammonia, clavulanic acid, etc.) the user, before installing the fan at the installation site must verify that the environmental conditions are compatible with the intended use of the materials that compose the fan.

5. INSTALLATION

After fan has been delivered but before fitting and installation, check condition of the consignment: in the event of discrepancy or damage to the machine, the manufacturer or carrier must be informed immediately.



WARNING Fitting and installation of the fan must be performed by specialized personnel, in order to prevent damage to the equipment or hazards to people as a result of faulty fitting.

Fitting the fan must be carried out according to the following stages:

- positioning and anchoring the fan;
- connection to the mains electricity supply;
- operational testing and putting into operation.

5.1 Choice of site and checking installation requirements

The user is responsible for preparing an area suitable for installation of the equipment and complying with the requirements laid down by European directives and national law governing safety at places of work. Environmental conditions for operating the equipment are as follows:

Ambient temperature during	Ambient humidity during operation
-15°C / +40°C	< 90%

For operation of fan installation, a manoeuvring area must be made available that is suitable for the fan dimensions and the chosen lifting equipment: electrical points must be provided in the installation area for fan connection to the mains electricity supply.



WARNING Our standard fans are delivered as fixed speed.

Upon request we can supply fans with the following features :


- "multispeed" where the speed variation can be made by using **ONLY** an autotransformer
- "multispeed with inverter (or VFD)" where the variation of speed is made by using an inverter (Variable Frequency Drive)

The "multispeed" machines cannot in any way be regulated by an inverter and the "multispeed with inverter" machines cannot in any way be regulated by an autotransformer.

Irrespective of the place of installation, suitable indelible warning signs are attached to the fan, warning of danger and giving instructions to remain at a safe distance not to place hands inside the shutter and not to run in proximity of the fan.




The warning signs are yellow, self-adhesive and indelible. They are fitted to the front and rear of the fan, and marked with the numbers A-1997 and B-1997 (see fig.10).




The area adjacent to the fan in the premises from which air is being extracted must be kept clear to allow the air to exit freely. It is also prohibited for anyone to remain in this area, because of the presence of organic gases and dust which may be present in the airflow.




5.2 Assembly of the EC52 cone

Fans are delivered with the cone disassembled to minimise space usage during transportation. To move the EC52 cone to its working position, it is necessary to follow the steps indicated below.


 <p>fig.11</p>	<ol style="list-style-type: none"> 1. Take two sectors of the cone.
 <p>fig.12</p>	<ol style="list-style-type: none"> 2. Align the four fingers of one of the two cone sectors to the respective slot of the other. 3. Slip in the sector with the fingers facing downwards; assuring to align the hole for fixing the screw.
 <p>fig.13</p>	<ol style="list-style-type: none"> 4. Repeat from step 2, using the remaining two sectors, steering the fingers on the same side. 5. Close the cone steering the fingers internally.




 <p>fig.14</p>	<p>6. Fix the cone sectors together by using 1 screw, 2 washers and 1 nut. Repeat the operation 8 times.</p>
 <p>fig.15</p>	<p>7. Place the round mesh on the discharge cone.</p>
 <p>fig.16</p>	<p>8. Bolt all the grommet to the cone by using 1 screw, 2 washers and 1 nut.</p>




5.3 Assembly of the EC50 cone

Fans are delivered with the cone disassembled to minimise space usage during transportation. To move the EC50 cone to its working position, it is necessary to follow the steps indicated below.




 <p>fig.19</p>	<p>11. Join one by one by means of 2 screws, 2 spring washers and 2 nuts. To obtain the discharge cone join the first sector with the last one.</p>
 <p>fig.20</p>	<p>12. Place the round mesh on the discharge cone.</p>
 <p>fig.21</p>	<p>13. Bolt all the grommet to the cone by using 1 screw, 2 washers, 1 spring washer and 1 nut.</p>



5.4 Placement of fans



WARNING There must be no obstacle neither in front or behind the fans. The outgoing airflow must be kept free at least of a length of 3-times fan diameter and the ingoing airflow must be kept free at least in a radius of 1.5 m distance in front of the fan.



Multiple rows




fig.24a – EC52




fig.24b – EC50



WARNING Fans have to be installed taking care to have central support placed in correspondence of a concrete wall or a dedicated metal frame, which has to be strong enough to support the weight of the fan. This is mandatory for guaranteeing the correct functioning of the fans eliminating vibrations and avoiding possible malfunctioning.




fig.25



WARNING In order to comply with CE regulations, fans should be mounted so that the bottom of the fan is 2.7m or higher from the floor below it. If the fan is to be installed at a lower height it should be equipped with special safety meshes which are available as an optional extra.





Failure to install the safety mesh releases the manufacturer from all liability and shall be considered an improper use of the machine.

5.5 Connection to the electrical system

The fan is supplied without a command and control circuit, but with all the internal electrical connections already made.

At the fitting stage, the installer must set up a control panel in compliance with the requirements of standard IEC EN 60439-1, and arrange the wiring of the fan in accordance with the instructions in standards IEC EN 60204-1 and IEC 60364.

The electrical panel of the fan must generally be equipped with the following devices (bearing EC marking as per directive 2014/35/UE):

 <p>fig.26</p>	<p>Lockable isolating switch.</p>
 <p>fig.27</p>	<p>Magnetothermal switch (chosen to suit the power of the motor). The need to fit a switch of differential type depends on the configuration of the electrical system supplying the fan: it is the installer's responsibility to make this assessment in accordance with the instructions in standard IEC 60364.</p>
 <p>fig.28</p>	<p>Red emergency stop button, mushroom type, provided with mechanical locking and release by turning (in compliance with UNI EN ISO 13850). Operating the button must bring about the electromechanical isolation of the power supply to the electric motor (category 0/1 according to IEC EN 60204-1).</p>
 <p>fig. 29</p>	<p>Start/stop selector switch (with characteristics compatible with the nominal current of the motor), or main panel for managing the equipment, with control devices which act on the electrical supply to the fan.</p>



WARNING Do not supply power to the fan during installation stage.
Installer must issue a declaration of correct installation in accordance with applicable legislation in the country of use.

Connection to the power supply must be done by means of a thermal overload protection switch, whose size depends on motor power. For safety reasons the overload switch can be locked by a padlock, not supplied by Munters.

Electrical earthing must be carried out according to local regulations before the motor is connected to the supply voltage.




fig.30

Below are suggested wiring diagrams for connecting the fan to the mains electrical supply. These diagrams are however subject to local laws and regulations and should be modified if necessary to comply with such laws and regulations.




fig.31




fig.32

1 = Overload protection switch

2 = Circuit breaker

3 = Fan motor



NOTE Failure to operate the fan with an overload protection device will render the motor guarantee null and void. Such motor overload protection devices can be ordered from Munters and be supplied with the fans.



NOTE The connection cable must be completely extracted from the fan housing in order to avoid being damaged by moving parts.

To avoid excessive voltage drop, which can be harmful to electrical motors, care must be taken as to the thickness of cables used as well as the distance from the main electrical enclosure to the motor. Proceed as follows:

- check that the data shown on the plate correspond to the connection data;
- before connecting the device, make sure that the supply voltage matches the device voltage;
- use only cables suitable for the current intensity indicated on the identification plate of the device.

For the sizing of the section, follow the sizing principles imposed by the EN 61800-5-1 standard. The protective conductor must have at least the same section as the external conductor.

Standard fan motors have the following voltage and frequency:
230/400V three-phase 50 or 60 Hz.




fig.33

Motor specifications are written on the label stuck on the frame and motor (no. 1 and 2 in diagram).

To change the direction of rotation of a three-phase motor it is necessary to change the connection of two of the phases.



WARNING In the event of installations that do not comply with the directions given in this chapter, the manufacturer's liability ceases, along with the validity of the CE Declaration of Conformity.

The electrical lines must be laid in accordance with requirements of the laws applying in the place of installation, and in any event:

- they must be laid with cables of adequate section for the power of the fan and the length of the line itself;
- they must make an effective earth connection;
- they must have isolating devices and automatic protection against overload and short circuits.

Before activating the electrical supply to the machine by turning the isolator switch to position On, a series of checks must be made:

- check that the voltage and frequency of the power source correspond to those indicated in the equipment technical data and electrical diagram;
- check that the supply cables and the conductor providing external protection are correctly connected;

- check that the connections in the control and power circuits are properly tight;
- check that the intensity of the short-circuit expected at the connection terminals is compatible with the breaking power of the protection switch upstream of the electrical panel;
- check that the protection devices (fuses, magnetothermic switches) are correctly sized, and that the phases are connected in the correct order: check that the fan rotates in the direction of the arrow shown on the driven pulley (see fig.34).




fig.34

Equipotential earthing wiring safeguard

To create effective protection against the risk of electrocution, the outer protection conductor must be connected to terminal PE inside an electrical panel.

For correct sizing of the protection conductors, see following requirements as indicated in standard IEC EN 60204-1:

- phase conductor up to 16 mm²: section of the protection conductor equal to the section of the supply conductor;
- phase conductor between 16 and 35 mm²: section of protection conductor equal to 16 mm²;
- phase conductor over 35 mm²: section of protection conductor equal to at least half the section of the supply conductor.



WARNING When connecting all the metal masses to the earth system, check that there are no insulating elements between the various conductive masses (metal parts). The system must not be put into operation unless the equipotentiality of the masses and the connection to the earth system have previously been checked.

Protection against contact voltages

The choice of device to protect the electrical system must be made in such a way as to ensure the safe intervention of the main automatic switches and any differential devices linked to them. For an appropriate choice of the type of protection for the machine's supply line, taking into account whether the distribution system is TT or TN, it is advisable to consult an electrical systems designer, in order to ensure compliance with the requirements of standard IEC 64-8 or the equivalent provisions in the country where the machine is being installed.

5.6 Tests and checks before startup

Before startup, it is extremely important to carry out a very careful check of the fan, in order to prevent malfunctions and/or accidents.

In particular, perform the following operations:

1. Equipotential earthing wiring safeguard:
 - check the fan visually, verifying that there are no particular mechanical irregularities or foreign bodies inside the structure;
 - check that the protective structures (fixed guards made of metal mesh) are correctly positioned and fixed;
 - check that the emergency stop function actuator operates correctly.



WARNING Tension the belt after three days of operation: improper tension will lead to premature wear on the transmission devices.

2. Checking the electrical system:
 - check that the supply conductors are properly fixed to the terminals of the isolating switch;
 - check the connections of the conductors in the equipotential earthing wiring safeguard;
 - check that the guards inside the electrical panel are correctly positioned and fixed;
 - check that the safety devices are receiving power and are active, and check their effectiveness.

After this series of checks has been carried out, the fan is ready for its first startup.



WARNING Some models of our fans allow to adjust the number of revolutions through inverter (also called VFD). In case of adjustment made by VFD the installer has to pay particular attention to the following aspects:

- it is necessary that the resistance of the ground line to which the equipment are connected has a very low values (about 15-20 ohm) in order to avoid high currents that can flow through the motor bearings and damage them.
- It is necessary to install the proper line filters, to avoid interference and allow proper operation of the equipment.
- The minimum frequency of operation of the engines in the case of absence of a forced external ventilation is 30 Hz. In the case of an operating frequency below 30 Hz is necessary to provide an external forced ventilation to the engine.

6. INVERTER

This chapter illustrates the main characteristics of the inverter that equips E-Line version.

6.1 Working range

Voltage	Phases	Frequency
208 - 230Vac (-15% / +10%)	Single phase or 3-phases	50 or 60Hz
400 - 480Vac (-15% / +10%)	3-phases	50 or 60Hz

STAR: TN, TT and IT. DELTA corner grounded

Ambient working temperature:	-20°C ÷ 50°C
RH%	0 ÷ 95%

The Motor and Inverter are IP66

6.2 Leds

The device is equipped with two LEDs, one green and one red, which are used to signal different states of the device as shown in the following table:

Led Green	Led Red	Description
Off	Off	No power supply active
On	Off	Device working in the correct way
Off	Blinking	Alarm
Blinking	Blinking	Firmware updating

Connection scheme




fig.1 wiring diagram for single-phase models




fig.4 wiring diagram for three-phase models



The power cable must be separated from the signal cable as per regulations

The shield of the signal cables (On/Off and 0-10Vdc or Modbus) must be connected to the gnd on the control unit side and not to earth.

Tighten the M4 screws of the terminal block cover with a torque of 3 Nm.

6.3 Alarm

The following table shows the identification codes of the possible alarms that the device can generate:

Code	Description
1	Over Voltage: device supply voltage too high
2	Under Voltage: supply voltage too low
3	Temperature too high
4	Over Current (lock)
5	Loss of synchronism (lock)
6	Over Current
7	Loss of synchronism
8	Internal communication loss
9	Extra energy dissipated by the braking resistor
10	Broken fuse or loss of phase

6.4 Mobile device APP

When you open the app it start scan for nearby inverter devices, displaying a list of all the devices found.

To connect a device in the list, simply click on its address/name.

When connecting, the app may require you to enter the inverter pairing code which is the following: 123456.

The inverter maintains a list of devices coupled to it; in the event that the device (smartphone, tablet, etc.) with which the connection is made is not present in the list, the app will request the insertion of the pairing code while otherwise it will not require the insertion of any code.

Dashboard

This tab of the application displays a whole series of information that allows monitoring of the device.

The information displayed is shown in the following table.

Table 1

Parameter	Description
HW	Hardware type (400Vac or 230Vac)
FW MAIN	Firmware version (motor microcontroller)

FW INTERFACE	Firmware version (interface microcontroller)
FW BLE	Firmware version (BLE module)
Inverter status	State of the inverter (standby, run or alarm)
Alarm Code	Alarm code
IGBT Module Temperature	Temperature IGBT power module [°C]
NTC Sensor Temperature	Temperature NTC sensor inside the inverter [°C]
Measured Speed	Measured rotation speed [rpm]
VBUS DC	Measured internal DC Bus Voltage [V]
Vd	Inverter Direct Voltage [V]
Vq	Inverter Orthogonal Voltage [V]
Vtot	Inverter Total Voltage [V]
Id	Inverter Direct Current [A]
Iq	Inverter Orthogonal Current [A]
Itot	Inverter Total Current [A]
Frequency Set	Frequency of the magnetic field [Hz]
Motor Speed	Setpoint: rotation speed [rpm]
Motor Direction	Motor direction if 1 means clockwise, if 0 means counter- clockwise
Absorbed Power	Motor absorbed power [watt]

Setup parameters

This tab allows to modify the operating parameters of the motor. To view the contents of this tab you must enter the password 123456. The editable parameters are shown in the following table.



WARNING Changing the configuration parameters can compromise optimal functioning of the fan. We recommend, before making any changes to contact Munters customer service in order to avoid any issues.



WARNING the settings must be made with the motor supplied but stopped (rpm = 0).

Table 2

Parameter	Description
Modbus Address	Modbus Address Allow Value: [1;247] Default: 1
Enable 485	485 bus termination resistance enable Allow Value: [0; 1] 0 termination resistance disable 1 termination resistance enable Default: 0
Alarm Reset	Alarm reset Allow Value: 0
Enable under stop	Enable the rotation at minimum speed when the control voltage is lower than the minimum value. Allow value: [0; 1] The fan does not rotate if the driving voltage (0-10Vdc) is lower than the minimum voltage The fan rotates at the minimum speed if the driving voltage (0-10Vdc) is lower than the minimum voltage Default: 0
Acceleration	Motor acceleration [rpm/s] Allow value: [10; max Acc.]

	Default: Max Acc.
Deceleration	Motor deceleration [rpm/s] Allow value: [10; max Dec.] Default: Max Dec.

Parameter	Description
Boost/Reverse Configuration	<p>Enable the boost and/or reverse features</p> <p>Boost: when turned on, the fan will go quickly to maximum speed and then reach the rotation speed set by the controller. Should be used in fans with Butterfly.</p> <p>Reverse: when turned off, the fan decelerates until it stops, once stopped it will begin to rotate with the opposite direction of rotation to the standard one so to "attract" the butterfly and help to close the shutter. Can be used in fans with Butterfly.</p> <p>Allow value: [0; 3]</p> <p>0: Boost e Reverse disable</p> <p>1: Boost enable, Reverse disable</p> <p>2: Boost disable, Reverse enable</p> <p>3: Boost and Reverse both enable</p> <p>Default: 0</p> <p>NOTE with these parameters, once received the command to "Off", the fan will start to automatically rotate in opposite direction for a time predetermined.</p>
Reverse time	<p>Fan rotation time in the opposite direction after receive a stop command [s]</p> <p>Allow value: [0; 32767]</p> <p>Default: 25 second</p>
Reverse speed factor	<p>Fan rotation speed setpoint during the Reverse rotation; expressed as a percentage of the maximum rotation speed [%]</p> <p>Allow value: [1; 100]</p> <p>Default: 60</p>
Boost ramp time	<p>Acceleration time to reach the maximum speed during the boost phase [s]</p>

	<p>Allow value: [2; 32767] Default: 10</p>
Boost maintain time	<p>Fan rotation time after reaching the maximum speed during the boost phase [s] Allow value: [0; 32767] Default: 5</p>
Parameter	Description
Start delay	<p>Delay in turning on the fan from the moment it receives the command from the control unit [s/10] Allow value: [0; 100] it means from 0 up to 10 sec Default: 0</p>
Fallback speed	<p>Rotation speed in case of Modbus communication loss Activate only if “Enable Live Command (Reg.1009) = 1” If the Reg. Enable Live Command is = 0 and the modbus connection is lost, the fan will continue to turn at the last operating speed before the loss of communication [rpm] Allow value: 0, [rpm min; rpm_max] Default: 0</p>
Slope swap	<p>This Switch reverses the slope of the relationship between 0-10V voltage and rpm. Allows you to reverse operation from: Low voltage, low Speed and high voltage, high speed → Low voltage, high speed and high voltage, low speed</p>

App screens




fig. 2 - Tab. 0 Dashboard Readings




fig. 1 - Tab.1 Settings




fig. 4 - Traffic Light: Alarm Log




fig. 3 - Start / Stop Fan

Firmware update

Using this tab, after entering the password (123456), it is possible to update the firmware of both microcontrollers inside the inverter if new features or bug fixings are available.

Before to go ahead remember to save your current settings.

The update procedure consists of four different phases: the verification of the communication protocol to be used for communication with the inverter, the transfer of the firmware update file, the safety stop of the fan rotation and finally the writing of the new firmware in the flash memory of the inverter.

The conclusion of the various phases is denoted by a green tick. Select the update file (*.upd), press the start procedure button and wait for the outcome.

At the end of the update don't forgot to download your saved settings.

Terms of use



WARNING In order to reduce the average lifetime and/or possible problems with the electrical components, it is recommended not to keep the inverter unpowered for long periods, we recommend therefore keep it powered (it does not need to work, it's enough that the supply voltage is applied to the inverter: green led On) for at least 24 hours once/twice per year

7. COMMISSIONING



WARNING The fan must not be used without first reading and understanding the user manual and becoming completely familiar with the controls.



WARNING Make sure the fan is disconnected from the mains before removing the safety devices.

7.1 Control devices

This chapter gives instructions on the control devices with which the electrical control panel must be fitted, which shall be done at the installation stage.

At the fitting stage, the installer must set up a control panel complying with the requirements of standard IEC EN 60439-1 and arrange the wiring of the fan in accordance with the instructions in standards IEC EN 60204-1 and IEC 60364.

The electrical circuit of the fan must generally be fitted with the devices indicated in section 5.3.

7.2 Instructions for starting up

Before starting the machine:

- check that all the guards for the hazardous areas are in their correct positions;
- check that all the electrical safety components are in place and check their effectiveness by activating them;
- check the presence of the electricity supply.

To start the fan, go through the following procedure:

- turn the isolator switch to position On;
- press the fan starter button.

Normal stopping

In the event of necessity the fan can be stopped by operating the relative control device (stop), which shall be installed on the electrical panel.

Activating this control must cause the fan blade to stop rotating, but does not cause isolation of the power supply: the fan can be started again by pressing the start button.

In the event that the fan does not need to be used for an extended period of time the following stop procedure must be used:

- operate the stop button
- operate the emergency stop button;

- open the main isolator switch (position “0”) on the electrical panel and attach a padlock to the actuator.



WARNING Interrupting the electricity supply, equivalent to isolating by the operator with the main switch, causes complete fan shutdown: restoring the electricity supply will not cause any movement in the machine.

Emergency stop

Operating the main emergency stop button causes the fan to stop moving.


The function is controlled by a red mushroom type button on a yellow background, provided with mechanical locking and release by turning. Operating it causes the instantaneous interruption of the power supply to the electric motor which makes the rotor turn (uncontrolled shutdown category 0 according to IEC EN 60204-1).

Resetting after stopping

1. Resetting after normal stopping
After normal stopping the operating cycle must be reset by following the procedure described in section 6.1.
2. Resetting after emergency stop
After an emergency stop, the operating cycle must be reset by following the procedure described below:
 - reset the actuator by which the emergency stop command was given (by turning the relative mushroom button);
 - for an exact reset sequence, refer to the instructions given in section 6.2.

8. TECHNICAL DATA

8.1 Dimensions






fig.36

A	B	C	D	E	F	G	H	I
1,380	1,380	1,500	1,500	85	450	630	270	M8

8.2 Technical specifications

EC52			
Models	1.0 hp	1.5 hp	2.0 hp
Number of blades	4		
Propeller diameter [inch]	mm 1,335 [52]		
Weight of fully equipped fan* [kg]	108	112	112
Airflow at 0 Pa [cfm]	m ³ /h 42,200 [24,900]	47,570 [27,971]	49,500 [29,100]
Airflow at 25 Pa [cfm]	m ³ /h 35,100 [20,700]	41,792 [24,574]	44,700 [26,300]
Airflow at 50 Pa [cfm]	m ³ /h 26,200 [15,400]	33,074 [19,448]	36,400 [21,400]
Specific performance at 0 Pa m ³ /h/W [cfm/W]	43.7 [25.7]	34.8 [20.4]	32.7 [19.2]

Max. operating temperature [°F]	°C 40 [104]		
Max. operating pressure [Pa]	50		
Nominal propeller speed [rpm]	386	438	462
IEC protective class of electric motor	IP55		
Electric motor winding insulation grade	F		
EC50			
Models	1.0 hp	1.5 hp	1.6hp E-Line
Number of blades	3		
Propeller diameter [inch]	mm 1,270 [50]		
Weight of fully equipped fan* [kg]	106	108	109
Airflow at 0 Pa [cfm]	m ³ /h 39,700 [23,340]	46,100 [27,120]	43500 [25,600]
Airflow at 25 Pa [cfm]	m ³ /h 33,7700 [19,840]	41,300 [24,280]	39000 [23,000]
Specific performance at 0 Pa m ³ /h/W [cfm/W]	39.7 [23.3]	30.4 [17.9]	35.5 [20.9]
Max. operating temperature [°F]	°C 40 [104]		
Max. operating pressure [Pa]	50		
Nominal propeller speed [rpm]	425	500	510
IEC protective class of electric motor	IP55		IP66
Electric motor winding insulation grade	F		H

*Excludes safety kit for installation below 2.7m above the floor.

Nominal Power [W] [Hp]		Phases	Speed	Frequency [Hz]	Voltage[V]	Current [A]	Rpm
EC52							
735	1	3	single	50	400	2.1	1400
735	1	1	single	50	230	5.2	1400
735	1	3	single	60	230/400	3.4/2	1800
735	1	1	single	60	230	5.7	1800
1100	1.5	3	single	50	400	3	1400
1100	1.5	3	single	60	230/400	4.3/2.5	1800
1500	2	3	single	50	400	3.6	1400
1500	2	3	single	60	230/400	5.6/3.3	1800
EC50							
735	1	3	single	50	230/400	3.2/1.9	1400
735	1	1	single	50	230	4.6	1400
735	1	3	single	60	230/400	3/1.8	1800
735	1	1	single	60	230	5.1	1800
1100	1.5	3	single	50	400	2.8	1400
1100	1.5	1	single	50	230	7.3	1400
1100	1.5	3	single	60	230/400	4.7/2.7	1800
1100	1.5	1	single	60	230	7.4	1800
1200	1.6	3	EC (E-Line)	50/60	400	3.3	1400

9. MAINTENANCE

9.1 Introduction

Maintenance must only be carried out by qualified personnel only using suitable tools and working methods. It is mandatory to purchase and use only original spare parts or those recommended by the manufacturer. The use of non-original spare parts or incorrect assembly exonerates the manufacturer from all liability.

Before any maintenance steps are taken, make sure the power switch is in the off position and locked by a padlock. Make sure the propeller is at a complete standstill.



WARNING The capacitor in single-phase motors can retain a charge which appears across the motor terminals even when the motor has reached standstill.

Fans do not contain parts needing periodic lubrication, as moving parts are either manufactured from self lubricating materials, or are sealed with lifetime lubrication.

9.2 Routine Maintenance Program

Following the maintenance program prepared by our experts is the best way to ensure the smooth operation of Munters fans, to improve their performance and to give a longer lifespan.

			ROUTINE MAINTENANCE				
			1 MONTH	2 MONTHS	2 YEARS	4 YEARS	5 YEARS
ACTIVITIES	BELT TENSIONING*	CHECK	✓				
	CLEAN DUST**			✓			
	BELT	REPLACE			✓		
	CENTRAL PULLEY					✓	
	CENTRIFUGAL SYSTEM**						✓
	PLASTIC BEARING**						✓

* Tighten belt for the first time after fan has been running for 3 days.

** No high-pressure water to be sprayed on motors and bearings.

9.3 Cleaning

Inspect the fan at regular intervals and keep it clean. It is advised to perform periodic cleaning of safety mesh guards. Dust on the safety mesh guards causes extra power consumption; severe dust on the motor can cause overheating and subsequent motor failure.



WARNING Keep motor body clean. Dust deposit on motor body will lead to overheating and failure of bearings and motor itself.

Do not use water for motor cleaning. Use compressed air only. Water spraying will cause rust inside the bearings and lead to their failure.



WARNING We recommend to avoid to use water for washing fans since the electric motors and the bearings of the central hub and centrifugal system support might get damaged by water infiltration. In case there is an

unbreakable need to use water for cleaning the fans, the electric motor, the central hub and the centrifugal weight mechanism have to be adequately protected by water sprays.



WARNING All the components and spare parts **MUST** be stored in dry and clean environment.

9.4 Belt tensioning check up

Check V-belt tension at regular intervals, the correct tension is obtained when maximum deflection (half-way from motor and central pulley) is about 10 mm, when pushed in by thumb.



WARNING Tighten fan belt after the fan has been running for 3 days. Without adjusting the tension, transmission components can wear out early.




fig.37

To reset the correct tension:

1. open the safety mesh guards;
2. unscrew motor slide fixing screws (without removing them);
3. tighten the V-belt by pushing the motor sideways;
4. tighten the fixing screws adequately;
5. fix the safety meshes guard to the fan housing.




WARNING Do not operate the fan with the safety protections removed: safety meshes can be removed only with specific tools by qualified technicians when the fan reaches a complete standstill.


The fixing systems of the safety protections are not interchangeable with other devices. Therefore, if for maintenance reasons the user damages or loses any component, this must be definitely ordered from the manufacturer as spare parts and it cannot just be replaced with other components, even similar, not supplied by the manufacturer itself. In this particular event the manufacturer refuses all responsibility on consequent damages caused to things and people and considers any kind of warranty lost.

10. SPARE PART LIST


EC52 exploded view




DETAIL A




DETAIL B




DETAIL C




DETAIL D: ALIGNMENT OF SHUTTER BLADE



POSITIONING OF PROPELLER FLANGE



ALIGNMENT OF REAR AND FRONT FLANGES



Spare parts EC52

REF.	DESCRIPTION	QUANTITY
1	ROUND CONE SAFETY MESH	1
2	CONE SECTOR	4
3	THREADED BUSH M8X12.5	2
4	POP UP RIVET 6.4x8	28
5	TOP PANEL	1

6	Ø8X32 WASHER	3
7	HEX SCREW M8x16	2
8	MOTOR*	1
9	HOOK FOR SPRING	2
10	RUBBER FOR CABLE	1
11	PLASTIC TIE ROD	2
12	CENTRAL PLASTIC BEARING RIGHT	1
13	PLASTIC BEARING RIGHT	9
14	SHUTTER BLADE	9
15	PLASTIC BEARING LEFT	9
16	METAL CLIP FOR MESH	10
17	Ø6.3×19 SELF-TAPPING SCREW	18
18	PYRAMIDAL SAFETY MESH	1
19	CENTRAL PLASTIC BEARING LEFT	1
20	CENTRAL SHUTTER BLADE	1
21	COVER PLATE	2
22	SIDE PANEL	2
23	BOTTOM PANEL	1
24	CONVEYOR	1
25	V-BELT*	1
26	M6X16 HEX SCREW	30


27	Ø6×24 WASHER	40
28	M6 HEX NUT THICK	28
29	Ø6 SPRING WASHER	12
30	CONE BRACKETS	4
31	HEXAGON SCREW M8X20	2
32	REAR FIXED FLANGE W/BUSH	1
33	HEX SCREW M8X30	4
34	PLAIN WASHER D8X24	3
35	PROPELLER FLANGE W/ BUSHES	1
36	PROPELLER*	1
37	M8 HEX NUT	10
38	HEX NUT M6 WITH FLANGE	4
39	HUB WITH AXLE	1
40	M6×30 HEX SCREW	4
41	CENTRAL PULLEY	1
42	WATERPROOF DISTANCE PIECE	1
43	CENTRAL SUPPORT	1
44	PLASTIC OVAL PLATE	2
45	M10×30 SCREW	4
46	EXT TOOTHED WASHER D10,5X18	4
47	M10 HEX NUT	4

48	FRONT DRIVER FLANGE	1
49	M25 HEX NUT	1
50	M8X16 HEX SOCKET CAP SCREW	6
51	THREADED BUSH M8X17.5	8
52	CENTRIFUGAL SYSTEM	1
53	PLAIN WASHER D8X16	2
54	SPRING WASHER D8	8
55	M8X30 HEX SOCKET CAP SCREW	2
56	PLASTIC FORK	1
57	BRASS PIN	1
58	HEX NUT M6X5	2
59	HEXAGONAL AXLE	1


* References change depending on the configuration utilized.

MOTOR PULLEY PITCH DIAMETER / HOLE / V-BELT				
	3 PHASE - ONE SPEED		1 PHASE - ONE SPEED	
	50 Hz	60 Hz	50 Hz	60 Hz
1 hp	90/19/A88	75/19/A86	90/19/A88	75/19/A86
1.5 hp	100/24/A88	80/24/A86	100/24/A88	80/24/A86
2 hp	106/24/A88	90/24/A86	-	-


EC50 exploded view




DETAIL A




DETAIL C




DETAIL D




DETAIL D: ALIGNEMENT OF SHUTTER BLADE



POSITIONING OF PROPELLER FLANGE



ALIGNMENT OF REAR AND FRONT FLANGES



Spare parts EC50

REF.	DESCRIPTION	QUANTITY
1	ROUND CONE SAFETY MESH	1
2	CONE SECTOR	4
3	THREADED BUSH M8X12.5	2
4	POP UP RIVET 6.4X8	28
5	TOP PANEL	1
6	Ø8X32 WASHER	3
7	HEX SCREW M8X16	2
8	MOTOR*	1
9	HOOK FOR SPRING	2
10	RUBBER FOR CABLE	1
11	PLASTIC TIE ROD	2
12	CENTRAL PLASTIC BEARING RIGHT	1
13	PLASTIC BEARING RIGHT	9
14	SHUTTER BLADE	9
15	PLASTIC BEARING LEFT	9
16	METAL CLIP FOR MESH	10
17	Ø6.3×19 SELF-TAPPING SCREW	18
18	PYRAMIDAL SAFETY MESH	1

19	CENTRAL PLASTIC BEARING LEFT	1
20	CENTRAL SHUTTER BLADE	1
21	COVER PLATE	2
22	SIDE PANEL	2
23	BOTTOM PANEL	1
24	CONVEYOR	1
25	V-BELT*	1
26	M6X16 HEX SCREW	34
27	Ø6×24 WASHER	24
28	M6 HEX NUT THICK	32
29	Ø6 SPRING WASHER	24
30	CONE BRACKETS	4
31	HEXAGON SCREW M8X20	2
32	REAR FIXED FLANGE W/BUSH	1
33	HEX SCREW M8X30	4
34	PLAIN WASHER D8X24	3
35	PROPELLER FLANGE W/ BUSHES	1
36	PROPELLER*	1
37	M8 HEX NUT	10
38	HEX NUT M6 WITH FLANGE	4
39	HUB WITH AXLE	1

40	M6×30 HEX SCREW	4
41	CENTRAL PULLEY	1
42	WATERPROOF DISTANCE PIECE	1
43	CENTRAL SUPPORT	1
44	PLASTIC OVAL PLATE	2
45	M10×30 SCREW	4
46	EXT TOOTHED WASHER D10,5X18	4
47	M10 HEX NUT	4
48	FRONT DRIVER FLANGE	1
49	M25 HEX NUT	1
50	M8X16 HEX SOCKET CAP SCREW	6
51	THREADED BUSH M8X17.5	8
52	CENTRIFUGAL SYSTEM	1
53	PLAIN WASHER D8X16	2
54	SPRING WASHER D8	8
55	M8X30 HEX SOCKET CAP SCREW	2
56	PLASTIC FORK	1
57	BRASS PIN	1
58	HEX NUT M6	2
59	HEXAGONAL AXLE	1

** References change depending on the configuration utilized.*

MOTOR PULLEY PITCH DIAMETER / HOLE / V-BELT				
	3 PHASE - ONE SPEED		1 PHASE - ONE SPEED	
	50 Hz	60 Hz	50 Hz	60 Hz
1 hp	95/19/A86	80/19/A86	95/19/A86	80/19/A86
1.5 hp	115/24/A88	95/24/A86	115/24/A88	95/24/A86
1.6 hp E-Line	125/24/A87		-	-

Requests for technical assistance and spare parts must be made directly to the manufacturer, at the following address:

Munters Italy S.p.A
Strada Piani, 2
18027 Chiusavecchia (IM), Italy
Tel: +39 0183 52 11
Fax: +39 0183 521 333
info@munters.it

Munters EC extraction fans are developed and produced by Munters Italy S.p.A., Italy



[Australia](#) Phone 61 2 8843 1594, agh.info@munters.com.au, [Brazil](#) Phone +55 41 3317 5050, contato@munters.com, [Canada](#) Phone +1 517 676 7070, aghort.info@munters.com, [China](#) Phone +86 10 8048 3493, marketing@munters.cn, [Denmark](#) Phone +45 98 623 311, aghort@munters.dk, [Germany](#) +49 (0) 25 58 - 93 92-0, [India](#) Phone +91 20 6681 8900, info@munters.in, [Indonesia](#) Phone +66 2 642 2670, info@munters.co.th, [Israel](#) Phone +972 3 920 6200, info@munters.co.il, [Italy](#) Phone +39 0183 5211, info@munters.it, [Japan](#) Phone +81 3 5970 0021, mkk@munters.jp, [Korea](#) Phone +82 2 7618 701, munters@munters.co.kr, [Mexico](#) Phone +52 818 2625 400, dhinfo@munters.com, [Singapore](#) Phone +65 7 446 828, info@munters.com.sg, [South Africa and Sub-Sahara Countries](#) Phone +27 11 997 2000, info@munters.co.za, [Spain](#) Phone +39 0183 5211, info@munters.it, [Sweden](#) Phone +46 8 6266 300, info@munters.se, [Thailand](#) Phone +66 2 6422 670, info@munters.co.th, [Turkey](#) Phone +90 262 7513 750, info@muntersform.com, [USA](#) Phone +1 517 676 7070, aghort.info@munters.com, [Export & Other countries](#) Phone +39 0183 5211, info@munters.it

Your closest distributor

Munters reserves the right to make alterations to specifications, quantities, etc., for production or other reasons, subsequent to publication
© Munters AB, 2024