

Evaporative Cooling Open Header Supplement

for CM Cooling (QM1125) and CS Cooling (QM1131)

For Open Header Cooling Systems, use the following steps in place of Steps 20 & 21 for CM cooling and Steps 24 & 25 for CS Cooling.

1) Slide pad retainer onto 6" stainless steel bolts and fasten in place with nylon wing nuts, **See Figure A.**

2) Holding the left end panel tight to the distribution cap, place the long side of the Angle Bracket on the pad retainer and the short side over end panel. **See Figure B.** Attach the angle bracket to the pad retainer using (2) #10 x 1/4" TEK screws (provided). Repeat for Right End Panel.

Proceed to the next step in your manual.

